


Preventative Maintenance BMP Fact Sheet

Pollutants of Concern



Vehicle Fluids Oil & Grease

Equipment
Fluids



Purpose

To prevent or reduce the discharge of pollutants from equipment and vehicles from entering storm drains.

Application

Equipment and vehicle maintenance operations.

Practices

- Conduct equipment and vehicle maintenance indoors whenever possible.
- Visually inspect vehicles, equipment, or systems which may malfunction and cause spills, leaks, or other situations / conditions that could lead to contamination of storm water runoff.
- Promptly repair or replace defective equipment found during inspection and/or testing.
- Replace worn parts prior to failure.
- Keep spare parts for equipment that needs frequent repair.
- Train employees on proper spill response procedures with the Spill Prevention BMP.

Frequency and Maintenance

- Regularly inspect equipment and vehicles for leaks. Repair or replace leaking components as needed.
- During regularly scheduled work activities involving equipment that could leak outside, inspect identified equipment and implement preventative maintenance as needed.
- Maintain spill response material (e.g., spill kit) in a location that easily accessible and known to personnel. Inspect spill kit materials on a regular basis (e.g., monthly) and replace as needed.

Training

Maintenance, shops, trades, and theater staff that perform outdoor work activities that could contribute pollutants to the campus storm water system must take the **Annual HAZCOM Training** which includes spill prevention, control, and cleanup; SDS's; and hazardous materials and waste management.

Additional Information • Refer to Spill Prevention, Control, and Cleanup procedures.
Refer to Equipment and Vehicle Maintenance procedures.